INSTALLATION INSTRUCTIONS



ELECTRIC

Vehicle Model: MAZDA BT50 / ISUZU D-MAX Year of manufacture: 2020 onwards



Caution

- Do not attach EGR RollTrac in a location or by a method not specified.
- Do not use this product for any vehicle make or model, other than those specified in this document.
- Do not remove the plaque or label from this product.
- Do not modify the structure of the EGR RollTrac in any way.

General Notes

- Read through the fitting instructions before installation of EGR RollTrac.
- Always install the accessory following the fitting instructions. Failure to do so may cause damage to the vehicle or the accessory.
- Ensure all recyclable discarded vehicle accessory components and packaging are recycled following local recycling regulations.
- It is always recommended that this accessory is fitted by a qualified Technician.
- Safely store and protect any removed vehicle components.
- Ensure all bare metal surfaces are protected using Automotive Bare Metal Primer and touch-up paint.
- Remove all metal swarf and dust from all vehicle surfaces if surface is used for accessory installation.





Safety Notes


- Check that all work practices comply with safety standards.
- Please wear appropriate clothing and use safety equipment.







































WHILE ROUTING THE VEHICLE HARNESS AVOID ANY VEHICLE COMPONENTS THAT HEAT UP, LIKE EXHAUST AND ENGINE COMPONENTS. DO NOT ATTACH HARNESS TO FUEL LINES AND AVOID PINCH POINTS.




STEP 1

Connect the vehicle harness (branch A) to the positive battery terminal and the negative (B) to the chassis existing earth point on the inner fender as shown.




IMPORTANT: Do not fit the fuses at this stage.



STEP 2


Remove driver kick panels & scuff plates by removing the hex nut and lifting it with flat screwdriver or trim removal tool.


Note: Remove the hex nut holding the kick panel first.



STEP 3


Using a Grommet Piercing Tool, punch a small hole in the grommet inside the engine bay on the fire wall near the petrol pump. Feed the Vehicle Harness (branch C) into the cabin on the passenger side through the rubber grommet. Note: Use a pull wire if required.






STEP 7

Feed the harness (branch D) down to the ground following the firewall and securing harness to the existing wiring.




STEP 8

Run the Vehicle harness (branch D) under the vehicle towards the rear. Secure the harness to the existing harness along the chassis rail.




STEP 9


Remove the front part of the rear LHS wheel arch liner.





SECTION C


EGR RollTrac ASSEMBLY





























SECTION E

- 1. Insert fuse to EGR RollTrac harness.
- 2. Make sure the tailgate is open.
- 3. Engage motor, pull out lever (clutch).
- 4. Make sure the vehicle is unlocked and driver door open.
- 5. Press both buttons and hold for 10 sec. until light illuminates.






- Cover will open and close twice automatically.
- The EGR RollTrac internal LED light will pulse slowly during calibration and stop pulsing when calibration is complete.




RT0045

OPENING AND CLOSING PROCEDURE


Electric Opening Procedure:





1. Press the front button on the EGR RollTrac side rail as shown.

Electric Closing Procedure:



1. Press the rear button on the EGR RollTrac side rail as shown.

NOTE: EGR RollTrac should open and close smoothly. If cover does not lock or open correctly, please refer to the trouble shooting section in the Owners Manual. If the EGR RollTrac closing is slow, clean the siderails and ensure that no dirt or debris is inside the drive rail.

Manual Opening and Closing Procedure:

Locate the Clutch Disengagement Lever on the RH side of the cover and push the Clutch inward to disengage the motor. Pull the cover rearward or forward as required. Before driving vehicle ensure you re-engage the clutch. **IMPORTANT:** If clutch was disengaged, calibration procedure needs to be re-run prior to electric operation.

